

## C-Series Replacement Syringes

Cat. #	10070	10071	10072	10073	10074	10075	10076
Volume	50 µL	100 µL	250 µL	500 µL	1 mL	2.5 mL	5 mL

**Materials:** UHMWPE Seal, Borosilicate Glass

**Fitting Interface:** 1/4 - 28

**Stroke:** 3 cm



Cat. #	10080	10081	10082	10083	10084	10085	10086	10088*
Volume	50 µL	100 µL	250 µL	500 µL	1 mL	2.5 mL	5 mL	12.5 mL

\*Compatible only with the TriContinent C3000 Model #8657-15 and C24000 Model #8657-11.

**Materials:** PTFE seal, Borosilicate Glass

**Fitting Interface:** 1/4 -28

**Stroke:** 3 cm



## SYRINGE REPLACEMENT

**To replace the syringe, prime all fluid from the syringe, and follow the steps below:**

1. To replace the syringe, lower the plunger driver.
  - For the C3000 pump, if the power is on, this can be done by sending the A3000R command or if the pump is powered off, manually lower the plunger by pushing firmly down on the syringe plunger holder.
  - For the C24000 pump, with the power on, send the A24000R command. You cannot manually lower the plunger on the C24000 pump.
2. Turn the plunger lock screw counterclockwise 3 turns.
3. Turn the syringe counterclockwise and remove from the valve.

**To install the syringe follow the steps below:**

4. Screw the threaded portion of the syringe clockwise into the valve.
5. Fully seat the plunger into the syringe plunger holder.
6. Securely tighten (clockwise) the plunger lock screw.
7. Initialize the pump.

