

User Guide: Sublym™ Kit
Compact Hot Embossing Machine

Contents.

Description	
Safety Notes	
List of Buttons	
Equipment Required	
Operating Instructions	
Advanced Sublym Features	1
Machine Maintenance	1
Terms & Conditions	1

SublymTM

DESCRIPTION

The Sublym^{\mathbb{M}} embossing machine allows fast and easy molding of Flexdym^{\mathbb{M}} polymer sheets. The machine is compact, measuring 33 x 34 x 11 cm3, allowing molding to be performed anywhere. The machine enables plug & play, and does not require a pressure source. It is adjustable to up to 180°C and suitable for molds up to 4 inches. The Sublym^{\mathbb{M}} allows Flexdym^{\mathbb{M}} molding to be accomplished within a few minutes.

SAFETY NOTES

The aim of this quick start guide is to illustrate how to use the Sublym™ system, to easily and rapidly create Flexdym™ chips. Please, always consult the safety notes or procedures that may be related to your specific heat press system prior to use.

As in all laboratory activities, gloves and lab coats should be worn at all times during the process. It is the user's responsibility to consult the manufacturer's recommendation for the chemicals used and if required to ensure adequate ventilation/extraction (e.g., via a fume hood) prior to proceeding.

The biggest risk for the user during the process is burning themselves. The equipment is hot and one must always wear heat resistant gloves while operating. As for all technical equipment the heat press has to be used only by a trained person to prevent any injury to the user or damage to the equipment.

LIST OF BUTTONS



EQUIPMENTS REQUIRED

PROCESS PARAMETERS	QUANTITY
SUBLYM™ EMBOSSING MACHINE	1
SCREW SPACERS	4
MASTER MOLD TO CREATE MICRON FEATURES ON FLEXDYM™	1
COUNTER MOLD TO CREATE SMOOTH SURFACE OPP FLEXDYM TM	1
FLEXDYM™ SHEET	1
PROTECTIVE PTFE SHEET	1
SCISSORS	1
TWEEZERS	1
ISOPROPANOL	1
HEAT RESISTANT GLOVES	1

*List of equiptments required to

Process.

OPERATING INSTRUCTIONS

Plug in the Sublym™ & switch the machine on (**)





Close the machine and pre-heat the mold chamber for a few minutes.

Press for 5 s to adjust & set the temperature

Press <u>ss</u> to start heating.

When pre-heating is complete, the machine beeps.

Press (5) 2x to turn off sound & stop pumping.

Tip: To change the temperature units between °C and °F, press "+" and "-" buttons at the same time. To monitor processing capacity (i.e. countdown of the number of runs), press 2s on "+" button and then press "-" button.

Note: The temperature & time of molding will depend on several parameters, e.g. sheet thickness, desired thickness, and channel resolution.



In a ductless fume hood, cut the Flexdym™ sheet using scissors, according to the size of your mold.

Note: Keep protective PTFE sheets to cover Flexdym™ after molding process.



Remove one protective PTFE sheet from the Flexdym™ and place the Flexdym™ on the counter mold using tweezers.

Note: The counter mold can be treated with silicone spray to improve releasing (of large mold surfaces). Use isopropanol or ethanol to clean the counter mold beforehand.





Remove the second protective PTFE sheet from other side of Flexdym™. Place the mold face down on the Flexdym™ sheet.

Note: The mold in the image is made of SU-8 on glass. However, Flexdym is compatible with other molds, e.g. SU-8 on silicon or epoxy molds.



Once molding is complete, remove the Mold-Flexdym-Counter mold sandwich from the Sublym™ molding chamber. (Isothermal Process) Allow to cool down at room temperature for 1-2 minutes.

Note: To speed up the process, you may use an air gun.



Open the Sublym™ & check the inner deformable membrane is attached correctly.



Unmolding

Remove Mold-Flexdym ensemble from counter mold very gently, using tweezers.

The addition of a small amount of isopropanol solution to the Flexdym™



Setting Up a Program

To set up a program press or

Press to adjust the temperature.

Press again to set the temperature.

Press (to adjust the time.

Press again 0 to set the temperature.



Using protective gloves & tweezers, place Mold-Flexdym-Counter mold sandwich in Sublym™ molding chamber.

Tip: Final thickness of Flexdym[™] can be adjusted using different spacers.

An estimate calculation:

Height of Spacers = Mold Thickness + Flexdym final thickness + 5mm



Gently remove the molded Flexdym[™] from the mold.

helps to release the counter mold.



Ensure a thin PTFE sheet (red) is placed on top of the sandwich to avoid sticking to inside of the metal cover.



Cover both sides of the Flexdym™ with the protective PTFE sheets. Cut neatly around the molded design.



Close the molding chamber & the Sublym™.

Press to start pumping & molding.

This process usually only takes a few minutes. Once done, the vacuum pump will automatically stop, and the machine will beep.

Press 💈 to turn off sound.

Note: Pressure inside chamber should stabilize between 0.08-0.06 MPa



Optional: Use metal hole punch pliers to create inlet/outlet holes in the design.

EDEN MATERIALS - SUBLYM USER GUIDE

ADVANCED SUBLYM FEATURES

There are additional advanced features in the Sublym™ system:

To set an automatic pre-heating step delay (up to 2min long), press () for 5 s.



To change the temperature unit of the machine between °C and °F, press the "+" and "-" buttons at the same time.

To monitor the processing capacity (countdown of the number of runs), press the "+" button for 2 s, then press the "-" button.

MACHINE MAINTENANCE

The Sublym™ system requires very little cleaning and maintenance. If Flexdym™ flows out of the molding chamber or sticks to the chamber lid, make sure you clean it as soon as possible using isopropanol. For any additional questions, please do not hesitate in contacting us at support@eden-microfluidics.com.

TERMS & CONDITIONS

We strongly believe in the intrinsic quality of our microfluidic products and we hope that you will be pleased with your purchase. However, in the unlikely event that you should receive damaged or incorrect goods, please notify us within 7 days of receipt and you will be offered the option of a refund or an exchange (provided the goods are in stock).

You may be asked to return goods for inspection. In this case we will refund the shipping fees. Please note that goods that become damaged or broken after 7 days of receipt cannot be returned.

Unwanted items

If for any reason you do not wish to keep your purchase and would like a store credit, then please notify us within 7 days of receipt.

We cannot accept unwanted returns that have been opened, used or damaged by the customer. For unwanted goods, we allow up to 14 days for the returns of goods. We will only issue a credit upon receipt of all returned goods.

Please note that we are unable to refund your costs in returning unwanted goods or the delivery costs of sending the goods to you in the first place.

Privacy policy

Customer details remain private and confidential and will not be released to a third party unless required to do so by law. We use the information we collect to process orders, to provide more personalized shopping experience and, if you request it, to notify you about new products, special offers or other information that may be of interest to you.

Payment and Procedure

Payment from private customers must be paid for in advance of shipment. Trade orders from registered companies or organization can be invoiced.

Payment is due strictly within 30 days of the invoice date.

Products and prices

Please note that some goods may vary in style, color or detail from the image shown online. We reserve the right to change prices at any time.

Transport and storage

Please prevent damage to your Eden Tech products by taking extra care when moving. Products must not be transported while plugged in or hot. Store products in standard room condition and in an adapted box.

Exclusive remedies

The remedies provided herein are the customer's sole and exclusive remedies. Eden Tech shall not be liable for any direct, indirect, special, incidental, or consequential damages, whether based on contract, tort, or any other legal theory.

